



IMPORTANT



FITTING TIPS

- **ALWAYS APPLY DECALS AT ROOM TEMPERATURE AND PRE HEAT WITH A HAIR DRYER OR HEAT GUN IF NECESSARY.**
- **ALL SURFACES MUST BE CLEANED (INCLUDING NEW PLASTICS) WITH CONTACT CLEANER OR ISOPROPANOL ALCOHOL.**
- **FIRMLY APPLY THE DECAL, EVENLY PUSHING THE DECAL OUT IN THE DIRECTION YOU ARE FITTING IT.**
- **USE A HAIR DRYER OR HEAT GUN TO HEAT THE DECAL TO APPLY ANY COMPLEX CURVED AREAS.**
- **IF NECESSARY, TRIM ANY AREAS THAT ARE INCORRECTLY FITTED AND OVERHANGING.**
- **AFTER EACH DECAL IS FITTED YOU MUST APPLY HEAT TO ALLOW THE DECAL TO MOULD AND THE ADHESIVE TO BOND TO THE SURFACE.**
- **ALLOW 24 HOURS FOR THE DECAL TO BOND AT ROOM TEMPERATURE BEFORE USE.**